


Color Theory – Part 4

Color Tolerances

Color Theory – Part 4

Color Tolerances





Review - A Colorimetric Description


datacolor

Defining a numerical system for color perception

Academy

We have described the visual color perception process by showing how the light source, object and observer are together responsible for color perception.

X








Object (Apple)




Human Observer

Color
Perception


With the Standard Observer, we can now develop a numerical specification:



Daylight Illuminant Numerical Data



Reflectance Curve Numerical Data




CIE Standard Observer Numerical Data


Colorimetric Description


Review


Standard Observer / Metamerism












Review - CIELAB

datacolor


3 Dimensions of Color – Hue, Chroma, Lightness



Review - CIELAB

<u>datacolor</u>

CIE L*a*b* Color Space



Review - CIELAB Color Difference

Std. CIE Z

9.29

3.06

5.58


datacolor

Academy

Red Apple 1 and Red Apple 2




Current Illumi Std. Name



13.60

18.83

15.91



Std. CIE L

43.65

50.49

46.86

Std. CIE a

48.50

51.01


47.48

Std. CIE b

14.38

26.02

20.42



50.58

57.26

51.68

Std. CIE h

16.51


27.03

23.27


Std. CIE C


100		7
06		
88		
20		•
9		
8		
40		
8	<u> </u>	
50	<u> </u>	
0		
	400 420 440 460 480 500 520 540 560 580 600 620 640 660 680 Wavelength [m]	700

D65 10 I	Deg R	ed Apple 1	21.65
A 10 De	g		34.21
F11 10 C)eg		26.83
	-		h



Std. CIE X





Delta CieLab D65 / 10 A / 10 F11 / 10	
+γρ,	+ <u>ΔΓ</u> *
more yellow	
n /	7
Stronger	-
30	0
Weaker	7
ú	· · · · · ·
ry more blue	
-4 -3 -2 -1 0 1 2 3 4	-∇Γ _*
-ΩD	

Current Illumi	Batch Name	Batch CIE X	Batch CIE Y	Batch CIE Z	Batch CIE L	Batch CIE a	Batch CIE b	Batch CIE C	Batch CIE h
D65 10 Deg	Red Apple 2	24.30	16.28	11.16	47.34	44.58	15.16	47.09	18.78
A 10 Deg		37.04	21.62	3.62	53.62	46.57	26.30	53.49	29.45
F11 10 Deg		30.77	19.11	6.90	50.82	45.29	20.79	49.84	24.66

CIELAB Color Difference – DL*, Da*, Db*, DC*, DH*, DE*

Current Illumi	Batch Name	CIE DL	CIE Da	CIE Db	CIE DC	CIE DH	CIE DE
D65 10 Deg	Red Apple 2	3.69	-3.92	0.78	-3.50	1.93	5.44
A 10 Deg		3.13	-4.44	0.28	-3.78	2.34	5.44
F11 10 Deg		3.96	-2.19	0.37	-1.85	1.23	4.54



Update - Color Difference

datacolor


Academy

CIELAB Polar Coordinates – DL*, DC*, DH*

$$C^* = (a^{*2} + b^{*2})^{1/2}$$
 $h = tan^{-1} (b^*/a^*)$
 $DL^* = L^*_{BAT} - L^*_{STD}$
 $(+ is lighter)$
 $(- is darker)$
 $DC^* = C^*_{BAT} - C^*_{STD}$
 $(+ is more chroma)$
 $(- is less chroma)$

DH* = $2(C^*_{STD} * C^*_{BAT})^{1/2} \sin (dh/2)$ (+ is counter-clockwise)

$$DE^* = (DL^2 + DC^2 + DH^2)^{1/2}$$



Color Tolerances

datacolor Academy

Acceptability versus Perceptibility

Perceptibility defines a just-noticeable difference between a standard and a batch.

Acceptability is the largest acceptable difference between a standard and a batch.

Color tolerances are the colorimetric limits that define when a product is acceptable.

Realistic tolerances are usually based on the maximum acceptable color difference rather than on a minimum perceptible difference.

A color tolerance is the amount of color difference or variation that is commercially acceptable.

Color tolerances will vary across industries. A good tolerance represents a compromise between the capability of the process and the customer's requirements.


DE* Tolerance


Defines a Sphere in CIELAB Color Space



Academy

DE* tolerance of 1.0 defines a sphere with a radius of 1.0 CIELAB Units.






DE* Tolerance


Defines a Box in CIELAB Color Space



Academy

DL*, Da*, Db* tolerance of 1.0 defines a box in CIELAB space.






DE* Tolerance


datacolor

Defines a Box in CIELAB Color Space

Academy


Tolerance DL* = \pm 1.0, Da* = \pm 1.0, Db* = \pm 1.5 defines a box in CIELAB space.





datacolor


Academy From Historical Batch Data



Visually Evaluate Each Batch as Pass or Fail



Academy




Batches are marked either as visually acceptable (Pass) or unacceptable (Fail).

DE* - Spherical Tolerance



Academy




A single DE* value cannot include the Pass batches and exclude the Fail batches.

Rectangular DL* Da* Db*



Academy




A rectangular da* and db* value cannot include acceptable batches and exclude unacceptable batches.

Polar L* C* h



Academy




A tolerance based on dh and DC* gets close but still can't quite get there.

Rectangular L* C* H*



Academy




A tolerance based on DH* and DC* also gets close but still can't quite get there.

Ellipsoidal L* C* H*



Academy




An elliptical tolerance based on DH* and DC* can include the acceptable batches and exclude the unacceptable ones.

datacolor


Academy

Ellipsoidal Tolerancing

DE*



Ellipsoid



$$\Delta E_{CMC(l:c)}^* = \left[\left(\frac{\Delta L^*}{l S_L} \right)^2 + \left(\frac{\Delta C_{ab}^*}{c S_C} \right)^2 + \left(\frac{\Delta H_{ab}^*}{S_H} \right)^2 \right]^{1/2}$$


 S_L = Lightness Tolerance

S_C = Chroma Tolerance

 S_H = Hue Tolerance

! = Lightness Adjustment Factor

c = Chroma Adjustment Factor





datacolor

Academy

Pass/Fail Considerations


$$\Delta E_{CMC(l:c)}^* = \left[\left(\frac{\Delta L^*}{l S_L} \right)^2 + \left(\frac{\Delta C_{ab}^*}{c S_C} \right)^2 + \left(\frac{\Delta H_{ab}^*}{S_H} \right)^2 \right]^{1/2}$$







Meaning of the Value of the CMC DE Academy



l = Lightness Factor
Allows adjustment of DL* Semi-axis

c = Chroma FactorAllows adjustment of DC* Semi-axis

$$\Delta E_{CMC(l:c)}^* = \left[\left(\frac{\Delta L^*}{l S_L} \right)^2 + \left(\frac{\Delta C_{ab}^*}{c S_C} \right)^2 + \left(\frac{\Delta H_{ab}^*}{S_H} \right)^2 \right]^{1/2}$$

$$DE^*_{CMC} = 1.0$$

Batch is on surface of ellipsoid.

$$DE^*_{CMC} < 1.0$$

Batch is inside ellipsoid (Pass)

$$DE^*_{CMC} > 1.0$$


Batch is outside ellipsoid (Fail)




Academy

Changing the Value of the CMC Lightness Factor from 1 to 2

c = 1



l = 2 c = 1




CIE 2000 Color Difference Equation

<u>datacolor</u>

Meaning of the Value of the CIE 2000 DE

Academy



$$\Delta E_{00}^* = \sqrt{\left(\frac{\Delta L'}{k_L S_L}\right)^2 + \left(\frac{\Delta C'}{k_C S_C}\right)^2 + \left(\frac{\Delta H'}{k_H S_H}\right)^2 + R_T \frac{\Delta C'}{k_C S_C} \frac{\Delta H'}{k_H S_H}}$$

Includes lightness, chroma and hue weighting factors
Improved gray colors
Improved performance for blue colors using rotational factor

 K_L = Lightness Factor Allows adjustment of DL* Semi-axis S_L = Lightness Tolerance

 $DE^*_{00} = 1.0$ Batch is on surface of ellipsoid.

 K_C = Chroma Factor Allows adjustment of DC* Semi-axis S_c = Chroma Tolerance

DE*₀₀ < **1.0**Batch is inside ellipsoid (Pass)

 K_H = Hue Factor Allows adjustment of DH* Semi-axis

 $S_H = Hue Tolerance$


DE*₀₀ > **1.0**Batch is outside ellipsoid (Fail)

Al Pass/Fail




Computer Generated Tolerance Based on Visual Acceptability

Academy




User can mark each batch as either a pass or fail and the program will try to create an ellipsoid that includes the pass samples and excludes the fail samples.




AI Generated Tolerance

datacolor

Light Gray Sample







AI Generated Tolerance

datacolor

Yellow Gold Sample







AI Generated Tolerance

datacolor

Orange Sample







Al Generated Tolerance

datacolor











Datacolor TOOLS examples



Webinar – Questions and Comments

Academy

CMC vs CIE2000

Are the differences between them worth changing? Are there negatives where CIE2000 isn't as good? What if mill is using CMC and Retailer is using CIE2000? Different DE*'s – CIELAB, CMC, CIE2000, DIN99, CIE94 – What to use?

If Spectrophotometer uses D65 light source, does the illuminant for Lab need to be specified?

Cases where DE is very close, but samples are visually far apart. Cases where DE is very large, but samples look good?

Color difference most accurate for color matching? Metamerism in architectural coatings?

DE* calculated by DL*,Da*,Db* same as by DL*,DC*,DH*? Yes.

DE's to different materials, any limitations?

Vector direction in color space?



Next session:

Academy

We will talk about visual and instrumental evaluations

Instrument Geometry

Integrating Sphere – d/0, 0/d


SCI, SCE

45/0, 0/45

Visual Evaluation

Light Booths

Follow-up on Questions





Want to learn more?

Sign up at <u>Datacolor Academy</u> for classroom style lectures and demonstrations covering useful color topics in select venues around the globe

Some useful reading material:

Do You Know How Humans See Color?

Follow <u>Datacolor Blog</u> for more useful information



Thank you and follow us:

Academy



www.facebook.com/DatacolorCorporate



www.linkedin.com/company/datacolor



www.youtube.com/user/DatacolorIndustrial